For: dwight
Printed on: Fri, Jul 12, 1991 12:51:19

Document: toc
Last saved on: Fri, Jul 12, 1991 09:10:32

pl2ps 4.0.5 Copyright 1988 Interleaf, Inc.

Contents

Introduction 1-1
Overview 1-1
Tools Required 1-1
Installation Procedure 1-1

Unpacking the System 2-1
Introduction 2-1
Before Unpacking the System Cabinets 2-1
Inspecting the iWarp System Shipment 2-1
Unpacking the System 2-2

Installation 3-1
Introduction 3-1
Installing the System Cabinet 3-1
Opening the Cabinet Doors 3-1
Joining Multiple Cabinets 3-2
Disconnecting the LED Connector Plate 3-2
Removing the Doors 3-4
Removing Side Grills 3-5
Connecting the Cabinets at their Bases 3-6
Connecting the Cabinets at their Tops 3-7
Attaching Front Base Filler Plates (Multiple Cabinets Only) 3-8
Attaching Rear Base Filler Plates (Multiple Cabinets Only) 3-8
Attaching the Cabinet Legs 3-10
Installing Cables Between Cabinets 3-10
Installing the External Interface Cables 3-11
Replacing the Doors 3-14
Closing the Cabinet Doors 3-14
Leveling the Cabinets 3-14

Power Up and Testing 4-1
Introduction 4-1
Applying Power 4-1
Running The Diagnostics 4-2
If Something Goes Wrong 4-5

List of Figures

Figure 1-1: iWarp System Installation Procedure 1-2
Figure 3-1: Disconnect the LED Cable from the Front of the System 3-3
Figure 3-2: L-Shaped Door Bracket 3-4
Figure 3-3: Remove the Side Grill 3-5
Figure 3-4: Wedge Adapter Castings and Cover 3-6
Figure 3-5: Splice Plate 3-7
Figure 3-6: Base Filler Plate Installation 3-9
Figure 3-7: Cabinet Leg 3-10
Figure 3-8: Remove the I/O Panel Cover 3-11
Figure 3-9: Connect the External Interface Cables to the iWarp I/O Panel . . 3-12
Figure 3-10: Connect the External Interface Cables to the SIB Board 3-13
Figure 4-1: Typical iWarp Diagnostic Test Results (Passed Tests) 4-3
Figure 4-2: Typical iWarp Diagnostic Test Results (Failed Tests) 4-5