Lecture 7: **Performance Optimization Part II:** Locality, Communication, and Contention

Parallel Computer Architecture and Programming CMU 15-418/15-618, Fall 2018


Today: more parallel program optimization

- **Recent lecture: strategies for assigning work to workers** (threads, processors, etc.)
 - Goal: achieving good workload balance while also minimizing overhead
 - Discussed tradeoffs between static and dynamic work assignment
 - Tip: keep it simple (implement, analyze, then tune/optimize if required)

Today: strategies for minimizing communication costs

Message-passing solver review (since it makes communication explicit)

Message passing model: each thread operates in its own address space




In this figure: four threads

The grid data is partitioned into four allocations, each residing in one of the four unique thread address spaces

(four per-thread private arrays)

Data replication is now required to correctly execute the program



Example:

After red cell processing is complete, thread 1 and thread 3 send row of data to thread 2 (thread 2 requires up-to-date red cell information to update black cells in the next phase)

"Ghost cells" are grid cells replicated from a remote address space. It's common to say that information in ghost cells is "owned" by other threads.

Thread 2 logic:

```
float* local_data = allocate(N+2,rows_per_thread+2);
int tid = get_thread_id();
int bytes = sizeof(float) * (N+2);
// receive ghost row cells (white dots)
recv(&local_data[0,0], bytes, tid-1);
recv(&local_data[rows_per_thread+1,0], bytes, tid+1);
// Thread 2 now has data necessary to perform
// future computation
```

Message passing solver

Similar structure to shared address space solver, but now communication is explicit in message sends and receives

// assume localA is initialized with starting values void solve() { bool done = false; while (!done) { float my_diff = 0.0f; if (tid != 0) if (tid != get_num_threads()-1) Send and receive ghost rows to "neighbor threads" if (tid != 0) if (tid != get_num_threads()-1) for (int i=1; i<rows_per_thread+1; i++) {</pre> for (int j=1; j<n+1; j++) {</pre> float prev = localA[i,j]; **Perform computation** (just like in shared address space version of solver) } } if (tid != 0) { All threads send local my_diff to thread 0 else { float remote diff; my_diff += remote_diff; **Thread 0 computes global diff, evaluates** } if (my_diff/(N*N) < TOLERANCE)</pre> termination predicate and sends result back to all done = true; other threads } }

int N:

}

int tid = get thread id();

Example pseudocode from: Culler, Singh, and Gupta

```
int rows_per_thread = N / get_num_threads();
float* localA = allocate(rows_per_thread+2, N+2);
// assume MSG_ID_ROW, MSG_ID_DONE, MSG_ID_DIFF are constants used as msg ids
       send(&localA[1,0], sizeof(float)*(N+2), tid-1, MSG_ID_ROW);
       send(&localA[rows_per_thread,0], sizeof(float)*(N+2), tid+1, MSG_ID_ROW);
       recv(&localA[0,0], sizeof(float)*(N+2), tid-1, MSG_ID_ROW);
       recv(&localA[rows_per_thread+1,0], sizeof(float)*(N+2), tid+1, MSG_ID_ROW);
         localA[i,j] = 0.2 * (localA[i-1,j] + localA[i,j] + localA[i+1,j] +
                              localA[i,j-1] + localA[i,j+1]);
         my_diff += fabs(localA[i,j] - prev);
       send(&mydiff, sizeof(float), 0, MSG_ID_DIFF);
       recv(&done, sizeof(bool), 0, MSG_ID_DONE);
      for (int i=1; i<get_num_threads()-1; i++) {</pre>
          recv(&remote_diff, sizeof(float), i, MSG_ID_DIFF);
       for (int i=1; i<get_num_threads()-1; i++)</pre>
         send(&done, sizeof(bool), i, MSD_ID_DONE);
```

Synchronous (blocking) send and receive

- send(): call returns when sender receives acknowledgement that message data resides in address space of receiver
- recv(): call returns when data from received message is copied into address space of receiver and acknowledgement sent back to sender

Sender:

Call **SEND**(foo) **Copy data from buffer 'foo' in sender's address** space into network buffer

Send message

Receive ack SEND() returns

Receiver:


Call RECV(bar)

Receive message Copy data into buffer 'bar' in receiver's address space Send ack **RECV() returns**

As implemented on the prior slide, there is a big problem with our message passing solver if it uses synchronous send/recv!

Why?

How can we fix it? (while still using synchronous send/recv)



Example pseudocode from: Culler, Singh, and Gupta

```
int rows_per_thread = N / get_num_threads();
float* localA = allocate(rows_per_thread+2, N+2);
// assume localA is initialized with starting values
// assume MSG_ID_ROW, MSG_ID_DONE, MSG_ID_DIFF are constants used as msg ids
     float my_diff = 0.0f;
     if (tid % 2 == 0) {
         sendDown(); recvDown();
         sendUp(); recvUp();
         recvUp(); sendUp();
         recvDown(); sendDown();
```

Non-blocking asynchronous send/recv

send(): call returns immediately

- Buffer provided to send() cannot be modified by calling thread since message processing occurs concurrently with thread execution
- Calling thread can perform other work while waiting for message to be sent

recv(): posts intent to receive in the future, returns immediately

- Use checksend(), checkrecv() to determine actual status of send/receipt
- Calling thread can perform other work while waiting for message to be received

Sender:	R
Call SEND(foo)	C
SEND returns handle h1	R
Copy data from 'foo' into network buffer	
Send message	
Call CHECKSEND(h1) // if message sent, now safe for thread to modify 'foo'	N C
	11

- leceiver:
- all RECV(bar) **ECV(bar) returns handle h2**
- leceive message **Nessaging library copies data into 'bar'** all CHECKRECV(h2) / if received, now safe for thread // to access 'bar'

Let's talk about... Pittsburgh



Pittsburgh is now hot stuff!

TRAVEL

36 Hours in Pittsburgh

36 Hours in Pittsburgh

Weekend Guide


By BRENDAN SPIEGEL JULY 15, 2015

By Fritzie Andrade, Louie Alfaro, Jessey Dearing, Andre



'Land of Opportunity' has real meaning here.





Beyond Pittsburgh's pretty downtown, transformation and mome art venues. By Fritzie Andrade, Louie Alfaro, Jessey Dearing, Andrew Hida





The Robots That Saved Pittsburgh

How the Steel City avoided Detroit's fate. By GLENN THRUSH 2/04/2014


What Millennials Love **About Pittsburgh**

And so is Bay Area rent...

THE NUMBERS

The Median Rent for an SF Two-Bedroom Hits \$5,000/Month

Friday, October 9, 2015, by Tracy Elsen



It's that time of month again when rental website Zumper puts out their monthly rent report and dashes San Franciscans' dreams of ever being able to move again. The new median rental price for a onebedroom in the city is \$3,620, up \$90 in just one month. That price is also up 13 percent over last year's mark. As Zumper points out, the even bigger increase has been in two-bedroom rents, which hit a \$5,000 median for the first time this month and are up 19 percent in a year. San Francisco remains, of course, the most expensive city in the country for rents.

Although San Francisco's median rent for a one-bedroom is exceptionally high, there are actually only eight neighborhoods at or above that median. The most expensive neighborhood is the Financial District, with a \$4,270 per month median rent for a one-bed. It is followed by Mission Bay/Dogpatch at \$3,900 and Pacific Heights at \$3,850. South Beach, Russian Hill, Potrero Hill, SoMa, and the Marina also sit above the median rent. And while the NoMad and Flatiron neighborhoods in New York are still more expensive than any neighborhood in San Francisco, the Financial District now has the same median one-bedroom rent as Tribeca, which used to sit far above any San Francisco spot.

RENT PRICES
SF RENT
THE NUMBERS
TOP
ZUMPER
6 COMMENTS
Like 2.9k

Hey, let's move to Pittsburgh! (all the cool tech kids are doing it!)

418SKILLZ

Camborghini




Everyone wants to get to Pittsburgh! (Latency vs. throughput review)

San Francisco Car's velocity: 100 km/hr


Distance: ~ 4,000 km

Latency of moving a person from San Francisco to Pittsburgh: 40 hours



Cars spaced by 1 km on highway


Throughput: 100 people per hour (1 car every 1/100 of an hour)








Improving throughput



Approach 1: drive faster! Throughput = 150 people per hour (1 car every 1/150 of an hour)



Cars spaced by 1 km on highway

Approach 2: build more lanes! Throughput: **300** people per hour (3 cars every 1/100 of an hour)



Review: latency vs throughput

Latency

The amount of time needed for an operation to complete. A memory load that misses the cache has a latency of 200 cycles A packet takes 20 ms to be sent from my computer to Google Asking a question on Piazza gets response in 10 minutes

Bandwidth

The rate at which operations are performed. Memory can provide data to the processor at 25 GB/sec. A communication link can send 10 million messages per second The TAs answer 50 questions per day on Piazza

What if only one car can be on the highway at a time?

When car on highway reaches Pittsburgh, the next car leaves San Francisco.



Latency of moving a person from San Francisco to Pittsburgh: 40 hours

Throughput = 1 / latency

= 1 / 40 of a person per hour (1 car every 40 hours)

Pittsburgh

Pipelining


Example: doing your laundry

Operation: do your laundry

- **1. Wash clothes**
- 2. Dry clothes
- 3. Fold clothes



Latency of completing 1 load of laundry = 2 hours



College Student 15 min


Increasing laundry throughput Goal: maximize throughput of many loads of laundry

One approach: duplicate execution resources: use two washers, two dryers, and call a friend



Latency of completing 2 loads of laundry = 2 hours **Throughput increases by 2x: 1 load/hour** Number of resources increased by 2x: two washers, two dryers


Pipelining Goal: maximize throughput of many l



Latency: 1 load takes 2 hours Throughput: 1 load/hour Resources: one washer, one dryer


Another example: an instruction pipeline

Break execution of each instruction down into several smaller steps Enables higher clock frequency (only a simple, short operation is done by each part of pipeline each clock)



Latency: 1 instruction takes 4 cycles **Throughput: 1 instruction per cycle** (Yes, care must be taken to ensure program correctness when back-to-back instructions are dependent.)

Intel Core i7 pipeline is variable length (it depends on the instruction) ~15-20 stages




Four-stage instruction pipeline:

IF = instruction fetch **D** = instruction decode + register read WB = "write back" results to registers


Analogy to driving to Pittsburgh example

Task of driving from San Francisco to Pittsburgh is broken up into smaller subproblems that different cars can tackle in parallel (top: subproblem = drive 1 km, bottom: subproblem = drive 500m)



Cars spaced by 1 km on highway

Throughput = 100 people per hour (1 car every 1/100 of an hour)



* Equivalent throughput to maintaining 1 km spacing of cars and driving at 200 km/hr





A simple model of non-pipelined communication **Example: sending a n-bit message**


$$T(n) = T_0 + \frac{n}{B}$$

- T(n) =transfer time (overall latency of the operation)
- $T_0 =$ start-up latency (e.g., time until first bit arrives at destination)
- *n* = bytes transferred in operation
- *B* = transfer rate (bandwidth of the link)

If processor only sends next message once previous message send completes...


"Effective bandwidth" = n / T(n)

Effective bandwidth depends on transfer size (big transfers amortize startup latency)




A more general model of communication **Example: sending a n-bit message**

Total communication time = overhead + occupancy + network delay



Example from: Culler, Singh, and Gupta

Pipelined communication



- = Overhead (time spent on the communication by a processor)
- = Occupancy (time for data to pass through slowest component of system)
- = Network delay (everything else)

Example from: Culler, Singh, and Gupta

Cost

The effect operations have on program execution time (or some other metric, e.g., energy consumed...) "That function has very high cost" (cost of having to perform the instructions) "My slow program sends most of its time waiting on memory." (cost of waiting on memory) "saxpy achieves low ALU utilization because it is bandwidth bound." (cost of waiting on memory)

Total communication time = overhead + occupancy + network delay **Total communication cost = communication time - overlap**

Overlap: portion of communication performed concurrently with other work "Other work" can be computation or other communication

Example 1: Asynchronous message send/recv allows communication to be overlapped with computation **Example 2: Pipelining allows multiple message sends to be overlapped**


Think of a parallel system as an extended memory hierarchy

I want you to think of "communication" very generally:

- Communication between a processor and its cache
- Communication between processor and memory (e.g., memory on same machine)
- Communication between processor and a remote memory (e.g., memory on another node in the cluster, accessed by sending a network message)


View from one processor Accesses not satisfied in local memory Proc cause communication with next level Reg So managing locality is important at Local L1 all levels Local L2 L2 from another core L3 cache Local memory **Remote memory (1 network hop)**

Remote memory (N network hops)



Two reasons for communication: inherent vs. artifactual communication

Inherent communication



Communication that <u>must</u> occur in a parallel algorithm. The communication is fundamental to the algorithm.

In our messaging passing example at the start of class, sending ghost rows was inherent communication


Communication-to-computation ratio

amount of communication (e.g., bytes)

amount of computation (e.g., instructions)


- If denominator is the execution time of computation, ratio gives average bandwidth requirement of code
- "Arithmetic intensity" = 1 / communication-to-computation ratio
 - I find arithmetic intensity a more intuitive quantity, since higher is better.
 - It also sounds cooler
- High arithmetic intensity (low communication-to-computation ratio) is required to efficiently utilize modern parallel processors since the ratio of compute capability to available bandwidth is high (recall element-wise vector multiple from lecture 2)

Reducing inherent communication Good assignment decisions can reduce inherent communication (increase arithmetic intensity)



elements communicated (per processor) \approx 2N

Reducing inherent communication



Asymptotically better communication scaling than 1D blocked assignment Communication costs increase sub-linearly with *P* **Assignment captures 2D locality of algorithm**

- elements communicated:

N

 $\frac{N^2}{P}$

 $\frac{N}{\sqrt{P}}$

 ∞

Artifactual communication

- Inherent communication: information that fundamentally must be **moved** between processors to carry out the algorithm given the specified assignment (assumes unlimited capacity caches, minimum granularity transfers, etc.)
- Artifactual communication: all other communication (artifactual) communication results from practical details of system implementation)

Artifactual communication examples

- System might have a minimum granularity of transfer (result: system must communicate more data than what is needed)
 - Program loads one 4-byte float value but entire 64-byte cache line must be transferred from memory (16x more communication than necessary)
- System might have rules of operation that result in unnecessary communication:
 - Program stores 16 consecutive 4-byte float values, so entire 64-byte cache line is loaded from memory, and then subsequently stored to memory (2x overhead)
- **Poor placement of data in distributed memories (data doesn't reside near processor** that accesses it the most)
- Finite replication capacity (same data communicated to processor multiple times because cache is too small to retain it between accesses)

Review of the three (now four) Cs You are expected to know this from 15-213!

Cold miss

First time data touched. Unavoidable in a sequential program.

Capacity miss

Working set is larger than cache. Can be avoided/reduced by increasing cache size.


Conflict miss

Miss induced by cache management policy. Can be avoided/reduced by changing cache associativity, or data access pattern in application.

Communication miss (new)

Due to inherent or artifactual communication in parallel system


Communication: working set perspective



Increasing capacity of hierarchy level


This diagram holds true at any level of the memory hierarchy in a parallel system Question: how much capacity should an architect build for this workload?

Does the graph on the previous slide look familiar?




Techniques for reducing communication

Data access in grid solver: row-major traversal




- Assume row-major grid layout. Assume cache line is 4 grid elements. Cache capacity is 24 grid elements (6 lines)
- Recall grid solver application. Blue elements show data in cache after update to red element.

Data access in grid solver: row-major traversal



- Assume row-major grid layout. Assume cache line is 4 grid elements. Cache capacity is 24 grid elements (6 lines)
- Blue elements show data in cache at end of processing first row.

Problem with row-major traversal: long time between accesses to same data



- four elements.

Assume row-major grid layout.

Assume cache line is 4 grid elements.


Cache capacity is 24 grid elements (6 lines)

Although elements (0,2) and (1,1) had been accessed previously, they are no longer present in cache at start of processing row 2

(What type of miss is this?)

This program loads three lines for every

Improving temporal locality by changing grid traversal order



Assume row-major grid layout.

- Assume cache line is 4 grid elements.
- Cache capacity is 24 grid elements (6 lines)

"Blocked" iteration order. (recall cache lab in 15-213)

Now three lines for every eight elements.

Improving temporal locality by fusing loops

```
void add(int n, float* A, float* B, float* C) {
  for (int i=0; i<n; i++)
      C[i] = A[i] + B[i];
}
void mul(int n, float* A, float* B, float* C) {
  for (int i=0; i<n; i++)
      C[i] = A[i] * B[i];
}
float* A, *B, *C, *D, *E, *tmp1, *tmp2;
// assume arrays are allocated here
// compute E = D + ((A + B) * C)
add(n, A, B, tmp1);
mul(n, tmp1, C, tmp2);
add(n, tmp2, D, E);</pre>
```

```
void fused(int n, float* A, float* B, float* C, float* D, float* E) {
    for (int i=0; i<n; i++)
        E[i] = D[i] + (A[i] + B[i]) * C[i];
}
// compute E = D + (A + B) * C
fused(n, A, B, C, D, E);</pre>
```

Code on top is more modular (e.g, array-based math library like numarray in Python) Code on bottom performs much better. Why?

Two loads, one store per math op (arithmetic intensity = 1/3)

Two loads, one store per math op (arithmetic intensity = 1/3)

Overall arithmetic intensity = 1/3

Four loads, one store per 3 math ops (arithmetic intensity = 3/5)

Improve arithmetic intensity by sharing data

- **Exploit sharing: co-locate tasks that operate on the same data**
 - Schedule threads working on the same data structure at the same time on the same processor
 - Reduces inherent communication

Example: CUDA thread block


- Abstraction used to localize related processing in a CUDA program
- Threads in block often cooperate to perform an operation (leverage fast access to / synchronization via CUDA shared memory)
- So GPU implementations always schedule threads from the same block on the same GPU core

Exploiting spatial locality

- Granularity of communication can be important because it may introduce artifactual communication
 - Granularity of communication / data transfer
 - Granularity of cache coherence (will discuss in future lecture)

Artifactual communication due to comm. granularity 2D blocked assignment of data to processors as described previously. Assume: communication granularity is a cache line, and a cache line

contains four elements



e required elements assigned to other processors


Good spatial locality for non-local accesses to top-bottom rows

> **Poor spatial locality for non-local** accesses to left-right columns


Inherently need one element from left and right neighbor, but system must communicate four.

Implication: artifactual communication increases with cache line size!

Artifactual communication due to cache line communication granularity



- Data partitioned in half by column. Partitions assigned to threads running on P1 and P2
- Threads access their assigned elements (no <u>inherent</u> communication exists)
- But data access on real machine triggers (artifactual) communication due to the cache line being written to by both processors *
- * further detail in the upcoming cache coherence lectures



Note: don't confuse blocked assignment of work to threads (true in both cases above) with blocked data layout in the address space (only at right)

4D array layout (block-major)


: @		
P10		
	• • • • • • • • • • • • • •	• • • • • • • • • • • • • •
		e 16
	$\begin{array}{c} \bullet & \bullet & \bullet & \bullet \\ \bullet & \bullet & \bullet & \bullet & \bullet \\ \bullet & \bullet &$	$\begin{array}{c} \bullet \bullet$

Consecutive addresses remain within single partition

Contention

Example: two students make appointments to talk to me about course material (at 3pm and at 4:30pm) - Operation to perform: Professor Mowry helps a student with a question

- Execution resource: Professor Mowry
- Steps in operation:
 - 1. Student walks from Gates Cafe to Prof. Mowry's office (5 minutes) =
 - 2. Student waits in line (??) =
 - Student gets question answered with insightful answer (5 minutes) = 3.




Time





Office hours from 3-3:20pm (no appointments)



Time

= Walk to Prof. Mowry's office (5 minutes)

= Wait in line


Problem: contention for shared resource results in longer overall operation times (and likely higher cost to students) 53

= Get question answered

Contention


- A resource can perform operations at a given throughput (number of transactions per unit time)
 - Memory, communication links, servers, TA's at office hours, etc.
- **Contention** occurs when many requests to a resource are made within a small window of time (the resource is a "hot spot")

Example: updating a shared variable



Flat communication: potential for high contention (but low latency if no contention)






Tree structured communication: reduces contention (but higher latency under no contention)

Example: distributed work queues serve to reduce contention (contention in access to single shared work queue)

Subproblems (a.k.a. "tasks", "work to do")

Set of work queues (In general, one per worker thread)

Worker threads: Pull data from OWN work queue Push new work to OWN work queue When local work queue is empty... STEAL work from another work queue



Example: create grid of particles data structure on large parallel machine (e.g, a GPU)


- **Problem: place 1M point particles in a 16-cell uniform grid based on 2D position**
 - Parallel data structure manipulation problem: build a 2D array of lists
- GTX 980 GPU: Up to 2048 CUDA threads per SMM core, and 16 SMM cores on the GPU

0	1	2	3
3• 4 5•	5	1 6 4 2 •	7
8	9 • ⁰	10	11
12	13	14	15

Cell	Count	Particle
id		id
0	0	
1	0	
2	0	
3	0	
4	2	3, 5
5	0	
6	3	1, 2, 4
7	0	
8	0	
9	1	0
10	0	
11	0	
12	0	
13	0	
14	0	
15	0	

Common use of this structure: N-body problems A common operation is to compute interactions with neighboring particles Example: given particle, find all particles within radius R

- - Create grid with cells of size R
 - Only need to inspect particles in surrounding grid cells



Solution 1: parallelize over cells

- One possible answer is to decompose work by cells: for each cell, independently compute particles within it (eliminates contention because no synchronization is required)
 - **Insufficient parallelism:** only 16 parallel tasks, but need thousands of independent tasks to efficiently utilize GPU)
 - Work inefficient: performs 16 times more particle-in-cell computations than sequential algorithm

```
list cell_lists[16]; // 2D array of lists
for each cell c
              // in parallel
  for each particle p // sequentially
      if (p is within c)
         append p to cell_lists[c]
```



Solution 2: parallelize over particles

- Another answer: assign one particle to each CUDA thread. Thread computes cell containing particle, then atomically updates list.
 - Massive contention: thousands of threads contending for access to update single shared data structure

list cell_list[16]; // 2D array of lists lock cell_list_lock; for each particle p // in parallel c = compute cell containing p

lock(cell_list_lock) append p to cell_list[c] unlock(cell list lock)

Solution 3: use finer-granularity locks

Alleviate contention for single global lock by using per-cell locks

- Assuming uniform distribution of particles in 2D space... ~16x less contention than solution 2

> list cell_list[16]; // 2D array of lists lock cell_list_lock[16];


> for each particle p // in parallel c = compute cell containing p lock(cell_list_lock[c]) append p to cell_list[c] unlock(cell_list_lock[c])




Solution 4: compute partial results + merge

Yet another answer: generate N "partial" grids in parallel, then combine

- **Example: create N thread blocks (at least as many thread blocks as SMX cores)**
- All threads in thread block update same grid
 - Enables faster synchronization: contention reduced by factor of N and also cost of synchronization is lower because it is performed on block-local variables (in **CUDA shared memory**)
- **Requires extra work:** merging the N grids at the end of the computation
- **Requires extra memory footprint:** Store N grids of lists, rather than 1






Solution 5: data-parallel approach									1	2	3
Step 1: compute particle_index:	e cell co 0	ntainir 1	ng each 2	particl 3	e (para 4	llel ove 5	r input particles)	3∙ 4 5∙	5	1 6 ⁴ • 2•	7
grid_index:	9	6	6	4	6	4		8	9_0	10	11
Step 2: sort resu particle_index:	oased on sort)	12	13	14	15						

particle_index:	3	5	1	2	4	0
grid_index:	4	4	6	6	6	9

Step 3: find start/end of each cell (parallel over particle_index elements)



This solution maintains a large amount of parallelism and removes the need for finegrained synchronization... at cost of a sort and extra passes over the data (extra BW)

This code is run for each element of particle_index array (each innovation has a unique valid of 'index')

	5		•••
	6		• • •
8	9	10	62 CMU 1

5-418/618, Fall 2018 UZ

Reducing communication costs

Reduce overhead of communication to sender/receiver

- Send fewer messages, make messages larger (amortize overhead)
- Coalesce many small messages into large ones

Reduce delay

- Application writer: restructure code to exploit locality
- HW implementor: improve communication architecture

Reduce contention

- Replicate contended resources (e.g., local copies, fine-grained locks)
- Stagger access to contended resources

Increase communication/computation overlap

- Application writer: use asynchronous communication (e.g., async messages)
- HW implementor: pipelining, multi-threading, pre-fetching, out-of-order exec
- **Requires additional concurrency in application (more concurrency than number** of execution units)

Summary: optimizing communication

Inherent vs. artifactual communication

- Inherent communication is fundamental given how the problem is decomposed and how work is assigned
- Artifactual communication depends on machine implementation details (often as important to performance as inherent communication)

Improving program performance

- Identify and exploit locality: communicate less (increase arithmetic intensity)
- Reduce overhead (fewer, large messages)
- Reduce contention
- Maximize overlap of communication and processing (hide latency so as to not incur cost)