ATM User-Network Interface Specification

Version 3.1

ATM User-Network Interface Specification
Version 3.1
September, 1994

(C) 1994 The ATM Forum. All Rights Reserved. No part of this publication may be reproduced in any form or by any means.

The information in this publication is believed to be accurate as of its publication date. Such information is subject to change without notice and the ATM Forum is not responsible for any errors. The ATM Forum does not assume any responsibility to update or correct any information in this publication. Notwithstanding anything to the contrary, neither The ATM Forum nor the publisher make any representation or warranty, expressed or implied, concerning the completeness, accuracy, or applicability of any information contained in this publication. No liability of any kind shall be assumed by The ATM Forum or the publisher as a result of reliance upon any information contained in this publication.

The receipt or any use of this document or its contents does not in any way create by implication or otherwise:

- Any express or implied license or right to or under any ATM Forum member company's patent, copyright, trademark or trade secret rights which are or may be associated with the ideas, techniques, concepts or expressions contained herein; nor

- Any warranty or representation that any ATM Forum member companies will announce any product(s) and/or service(s) related thereto, or if such announcements are made, that such announced product(s) and/or service(s) embody any or all of the ideas, technologies, or concepts contained herein; nor

- Any form of relationship between any ATM Forum member companies and the recipient or user of this document.

Implementation or use of specific ATM recommendations and/or specifications or recommendations of the ATM Forum or any committee of the ATM Forum will be voluntary, and no company shall agree or be obliged to implement them by virtue of participation in the ATM Forum.

The ATM Forum is a non-profit international organization accelerating industry cooperation on ATM technology. The ATM Forum does not, expressly or otherwise, endorse or promote any specific products or services.

Acknowledgements

A specification of the breadth and significance as is contained in this document is possible only through the efforts of many individuals. The assistance of the numerous members of The ATM Forum who have brought contributions towards, discussed and reviewed the enclosed information is appreciated. It must not be overlooked that the Technical Committee was able to complete this implementation agreement because of the solid base of work performed by regional and international standards groups.

Special thanks are due to the "enablers" - the UNI 3.1 editing team led by Greg Ratta (Gregan Crawford, Bob Fenaglio, Henry Fowler, John Sikora and Rick Townsend) and the UNI 3.0 editing team led by Jim Grace (Richard Breault, Rao Cherukuri, John Jaeger, Jeff Kiel, Kieth McCloghrie and Lou Wajnaroski).

George Dobrowski
Chairman
The ATM Forum Technical Committee

Preface

Since the publication of the ATM User-Network Interface Specification, Version 3.0 (UNI 3.0), a number of international standards have been completed. In particular, recent progress within the ITU for the following ITU-T Recommendations: I.610, Q.2100, Q.2110, Q.2130 and Q.2931 has bearing on the interface specified in UNI 3.0. This version, UNI 3.1, of the interface specification has been created to bring The ATM Forum implementation agreements in line with the recent agreements in international standards and is intended to allow interoperation of equipment designed to the ATM Forum implementation agreements and equipment designed to international standards.

It should be noted that these changes render this new version imcompatible with version 3.0 for signaling and signaling virtual channels.

Foreword

Asynchronous Transfer Mode (ATM) is widely acknowledged as the base technology for the next generation of global communications. ATM provides a unique ability to handle the real-time networking requirements of emerging multimedia applications, while providing compatibility with the increasing bandwidth needs for current installations. ATM solutions are being deployed throughout the wide area and enterprise network backbone, and all the way to the desktop and home. This User-Network Interface (UNI) document that you are reading defines the primary specification for end-system connection to ATM networks.

Progress toward the definition of global Asynchronous Transfer Mode (ATM) standards continues at a rapid pace. This is the second published edition of the ATM Forum UNI specification, and contains several new sections which further define the operation of ATM in Local and Wide Area Networks. It represents the next step in the process which will allow a uniform deployment of interoperable ATM technology.

The UNI specification is the result of the combined work of hundreds of companies from all sectors of the industry cooperating towards a common goal. The process which results in rapid convergence and final agreement of so many diverse interests on a single specification is both immense and mind-boggling. It is the strength and flexibility of the underlying ATM technology and its ability to best handle the many conflicting requirements that enables this continuing progress.

The Technical Committee of the ATM Forum creates the UNI specification. The committee meets every 2 months in different locations around the world for up to a week at a time. Typically over 500 people attend these meetings, representing a wide diversity of interests and knowledge. Technical contributions for the meeting, several hundred in number, are sent out electronically ahead of time to the entire membership. This allows participants to review the information before the actual meeting. Contributions are assigned to specific working groups of experts. After a period of discussion and voting, a single recommend document is forwarded to the ATM Forum membership for final review and approval.

From its initial formation in November of 1991, The ATM Forum has grown to over 600 member organizations at the time of this writing. A great deal of credit goes to the Technical Committee for its ability to maintain rapid progress in spite of the difficult logistics required to reach consensus between such a large number of participants.

The industry specifications from the ATM Forum are based on work of international standards organizations. Completion of this document is due to the active participation and dedication of member companies, and individuals who often give up much of their personal time to accomplish the work. I would particularly like to acknowledge the effort of George Dobrowski and Jim Grace, the Chair and Vice Chair of the ATM Forum Technical Committee for their leadership in guiding our diverse and ever-growing committee to final agreement.

Fred Sammartino
President and Chairman of the Board
The ATM Forum

Table of Contents

Section 1: Introduction 1
1.1 Purpose of Document 3
1.2 Scope of Document 4
1.3 Structure of Document 4
1.4 Terminology 5
1.5 ATM Bearer Service Overview 5
1.6 User-Network Interface Configuration 8
1.7 User-Network Interface Protocol Architecture 9

Section 2: Physical Layer Interfaces Specification 11
2.1 SONET STS-3c Physical Layer Interface 12
2.1.1 Physical Layer U-plane Specification 13
2.1.1.1 Physical Media Dependent (PMD) Specification 13
2.1.1.1.1 Physical Medium Characteristics at 155.52 Mbps 13
2.1.1.2 Transmission Convergence (TC) Sublayer Specification 14
2.1.1.2.1 B-ISDN Independent TC Sublayer Functions 14
2.1.1.2.2 B-ISDN Specific TC Sublayer Functions 14
2.1.1.2.2.1 HEC Generation/Verification 14
2.1.1.2.2.2 Cell Scrambling and Descrambling 15
2.1.1.2.2.3 Cell Mapping 15
2.1.1.2.2.4 Cell Delineation 15
2.1.1.2.2.5 ATM Payload Construction Indication 16
2.1.1.3 SONET STS-3c Frame at the UNI 16
2.1.2 Physical Layer Operation and Maintenance Specification (M-plane) 19
2.1.2.1 B-ISDN Independent Operation and Maintenance Functions 21
2.1.2.1.1 Performance Monitoring 21
2.1.2.1.2 Fault Management 22
2.1.2.1.3 Facility testing 22
2.1.2.2 B-ISDN Specific Operation and Maintenance Functions 22
2.1.2.2.1 Loss of Cell Delineation 22
2.2 DS3 Physical Layer Interface 23
2.2.1 Format at 44.736 Mbps 23
2.2.1.1 PLCP Format 25
2.2.1.2 PLCP Overhead Utilization 25
2.2.1.2.1 Framing Octets (A1, A2) 25
2.2.1.2.2 Bit Interleaved Parity - 8 (B1) 25
2.2.1.2.3 Cycle/Stuff Counter (C1) 26
2.2.1.2.4 PLCP Path Status (G1) 26
2.2.1.2.5 Path Overhead Identifier (P0-P11) 27
2.2.1.2.6 Growth Octets (Z1-Z6) 27
2.2.1.2.7 Trailer Nibbles 27
2.2.2 ATM Transfer Capability 28

2.2.3 Timing 28
2.2.4 Cell Payload Scrambling 28
2.2.5 Cell Delineation 28
2.2.6 HEC Generation/Verification 28
2.3 Physical Layer for 100 Mbps Multimode Fiber Interface 29
2.3.1 Physical Media Dependent (PMD) Specification 30
2.3.1.1 Physical Medium Characteristics 30
2.3.1.2 Line Coding 31
2.3.1.3 Line Rates and Bit Timing 32
2.3.2 Transmission Convergence (TC) Sublayer Specification 32
2.3.2.1 Idle Line 32
2.3.2.2 Cell Delineation 32
2.3.2.3 HEC Generation/Verification 33
2.4 Physical Layer for 155 Mbps Interface 34
2.4.1 Fiber Physical Medium Dependent Specification 34
2.4.1.1 Line Rates and Bit Timing 35
2.4.1.2 Fiber Optic Medium Characteristics. 35
2.4.1.3 Optical Medium Connector Plug and Socket. 36
2.4.1.4 Optical Characteristics 36
2.4.2 STP Physical Medium Dependent Specification 39
2.4.2.1 Line Rates and Bit Timing. 40
2.4.2.2 Electrical Medium Characteristics. 40
2.4.2.3 Electrical Medium Connector Plug and Socket. 40
2.4.2.4 Electrical Characteristics 41
2.4.3 Transmission Convergence (TC) Specification 43
2.4.3.1 Line Coding 43
2.4.3.2 Transmission Frame Structure 43
2.4.3.3 Frame and Cell Delineation 44
2.4.3.4 125 µsec Clock recovery 44
2.4.3.5 HEC Generation/Verification 45
2.4.4 Physical Layer Operation and Maintenance Specification (M-plane) 46
2.5 E3 Physical Layer Interface 47
2.6 E4 Physical Layer Interface 47

Section 3: ATM Layer Specification 49
3.1 ATM Layer Services 50
3.2 Service Expected from the Physical Layer 52
3.3 ATM Cell Structure and Encoding at the UNI 52
3.4 ATM Layer Functions Involved at the UNI (U-plane) 55
3.4.1 Multiplexing among different ATM connections 56
3.4.2 Cell rate decoupling 56
3.4.3 Cells discrimination based on pre-defined header field values 57
3.4.4 Cell discrimination based on Payload Type (PT) Identifier field values 59
3.4.5 Loss priority indication and selective cell discarding 60
3.4.6 Traffic Shaping 60

3.5 ATM Layer Management Specification (M-plane) 60
3.5.1 ATM Layer Management Information Flows 61
3.5.2 ATM OAM Cell Format 63
3.5.3 ATM Fault Management functions at the UNI 65
3.5.3.1 Alarm Surveillance 65
3.5.3.2 Connectivity Verification 66
3.5.3.2.1 End to End Loopback 67
3.5.3.2.2 UNI Loopback 67
3.6 Traffic Control and Congestion Control 68
3.6.1 Introduction 68
3.6.1.1 Objectives 69
3.6.1.2 Generic Functions 70
3.6.1.3 QoS, Network Performance and Cell Loss Priority 71
3.6.1.4 Relation with other Standard documents 71
3.6.2 User-Network Traffic Contract 72
3.6.2.1 Traffic Parameters and Descriptors 72
3.6.2.2 Traffic Contract Specification 74
3.6.2.3 Cell Conformance and Connection Compliance 75
3.6.2.4 Traffic Contract Parameter Specification 76
3.6.2.4.1 Generic Cell Rate Algorithm (GCRA) 77
3.6.2.4.2 Peak Cell Rate 79
3.6.2.4.2.1 Peak Cell Rate Reference Model 80
3.6.2.4.2.2 Peak Cell Rate Parameter Definition 81
3.6.2.4.2.3 Interpretation of the Definition of Peak Cell Rate and Equivalent Terminal 82
3.6.2.4.2.4 Cell Delay Variation Tolerance 82
3.6.2.4.3 Sustainable Cell Rate and Burst Tolerance 85
3.6.2.4.3.1 Sustainable Cell Rate and Burst Tolerance Reference Model 85
3.6.2.4.3.2 Sustainable Cell Rate and Burst Tolerance Parameter Definitions 85
3.6.2.4.3.3 Interpretation of the Definition of Sustainable Cell Rate and Burst Tolerance in Conjunction with Peak Cell Rate 86
3.6.2.4.3.4 Relationship of CDV Tolerance, SCR and Burst Tolerance 88
3.6.2.5 Conformance Definitions Supported at the Public UNI 89
3.6.2.5.1 Conformance Definition for PCR 89
3.6.2.5.2 Conformance Definition for PCR CLP=0+1 and SCR CLP=0 90
3.6.2.5.3 Conformance Definition for PCR CLP=0+1 and SCR CLP=0+1 90
3.6.3 Functions and Procedures for Traffic Control and Congestion Control at the UNI 91
3.6.3.1 Introduction 91

3.6.3.2 Traffic Control Functions 92
3.6.3.2.1 Network Resource Management 92
3.6.3.2.2 Connection Admission Control 95
3.6.3.2.3 Usage Parameter Control 96
3.6.3.2.3.1 UPC Functions 96
3.6.3.2.3.2 UPC Requirements 96
3.6.3.2.3.3 UPC location 98
3.6.3.2.3.4 Traffic parameters subject to control at the UPC 99
3.6.3.2.3.5 UPC actions 99
3.6.3.2.3.6 Relationship between UPC, CLP and Network Performance 100
3.6.3.2.3.7 Relationship Between UPC and OAM 101
3.6.3.2.4 Selective Cell Discard 101
3.6.3.2.5 Traffic Shaping (O) 101
3.6.3.2.6 Explicit Forward Congestion Indication 102
3.6.3.3 Congestion Control Functions 102
3.6.3.3.1 Selective Cell Discard 103
3.6.3.3.2 Reaction to UPC failures 103

Section 4: Interim Local Management Interface Specification 105
4.1 Interim Local Management Interface (ILMI) Functions 108
4.2 ILMI Service Interface 110
4.2.1 System (R) 111
4.2.2 Physical Layer (R) 112
4.2.3 ATM Layer (R) 112
4.2.4 ATM Layer Statistics (O) 112
4.2.5 Virtual Path Connections (R) 112
4.2.6 Virtual Channel Connections (R) 112
4.3 Simple Network Management Protocol (SNMP) 113
4.4 Management Information Base (MIB) Model for ILMI Managed Objects 113
4.4.1 Per-System UNI MIB Attributes (R) 113
4.4.2 Per-Physical Interface UNI MIB Attributes (R) 113
4.4.2.1 Common (R) 114
4.4.2.1.1 Interface Index (R) 114
4.4.2.1.2 Interface Address (O) 114
4.4.2.1.3 Transmission Type (R) 114
4.4.2.1.4 Media Type (R) 115
4.4.2.1.5 Physical Layer Operational Status (R) 115
4.4.2.1.6 Adjacency Information 115
4.4.2.2 Transmission Type Specific Information (R) 115
4.4.2.2.1 SONET STS-3c Physical Layer Interface 115
4.4.2.2.2 DS3 Physical Layer Interface 115
4.4.2.2.3 Physical Layer for 100 Mbps Interface 115
4.4.2.2.4 Physical Layer for 155 Mbps Interface 115

4.4.3 Per-ATM Layer Interface UNI MIB Attributes (R) 116
4.4.3.1 Interface Index (R) 116
4.4.3.2 Configuration Information (R) 116
4.4.3.2.1 Maximum Number of VPCs (R) 116
4.4.3.2.2 Maximum Number of VCCs (R) 116
4.4.3.2.3 Number of Configured VPCs (R) 117
4.4.3.2.4 Number of Configured VCCs (R) 117
4.4.3.2.5 Maximum Number of Active VPI bits (R) 117
4.4.3.2.6 Maximum Number of Active VCI bits (R) 117
4.4.3.2.7 ATM UNI Port Type (R) 117
4.4.3.2.8 ATM UNI Version (R) 117
4.4.4 ATM Layer Statistics (O) 117
4.4.4.1 ATM Cells Received (O) 118
4.4.4.2 ATM Cells Dropped on the Receive Side (O) 118
4.4.4.3 ATM Cells Transmitted (O) 118
4.4.5 Per-Virtual Path UNI MIB Attributes (R) 118
4.4.5.1 Interface Index (R) 119
4.4.5.2 VPI (R) 119
4.4.5.3 Transmit Traffic Descriptor (R) 119
4.4.5.4 Receive Traffic Descriptor (R) 119
4.4.5.5 Operational Status (R) 119
4.4.5.6 Transmit (QoS) Class (R) 119
4.4.5.6 Receive (QoS) Class (R) 119
4.4.6 Per-Virtual Channel UNI MIB Attributes (R) 120
4.4.6.1 Interface Index (R) 120
4.4.6.2 VPI (R) 120
4.4.6.3 VCI (R) 120
4.4.6.4 Transmit Traffic Descriptor (R) 120
4.4.6.5 Recieve Traffic Descriptor (R) 120
4.4.6.6 Operational Status (R) 120
4.4.6.7 Transmit (QoS) Class (R) 121
4.4.6.8 Receive (QoS) Class (R) 121
4.4.7 ILMI Traps (R) 121
4.5 Relationship to Other MIBs 121
4.5.1 Relationship to the 'system' group (R) 121
4.6 Actual MIB 122
4.6.1 Objects 122
4.6.1.1 Textual Conventions 123
4.6.1.2 Use of Counters 123
4.6.1.3 Meaning of Transmit/Receive 123
4.6.2 Definitions 123
4.7 ILMI Protocol 147
4.7.1 Use of VCCs 147
4.7.2 Message Format (R) 147
4.7.3 Message Sizes (R) 148

4.7.4 ILMI Traffic Requirements 148
4.7.5 Message Response Time 148
4.7.6 Object Value Data Currentness 149
4.7.7 Link Management Procedures 149

Section 5: UNI Signalling 151
5.1 General 151
5.1.1 Scope 151
5.1.1.1 Reference Configuration 151
5.1.2 Capabilities Supported by Phase 1 Signalling 153
5.1.2.1 Support of Demand (Switched) Channel Connections 154
5.1.2.2 Support of Point-to-Point and Point-to-Multipoint Channel Connections 154
5.1.2.2.1 Definition of Point-to-Multipoint Connection 154
5.1.2.2.2 Support of Point-to-Multipoint Channel Connections 155
5.1.2.3 Support of Connections with Symmetric or Asymmetric Bandwidth 155
5.1.2.4 Support of a Single Connection per Call 156
5.1.2.5 Protocol Support for Basic Signalling Functions 156
5.1.2.6 Support of Class X, Class A, and Class C ATM Transport Services ... 157
5.1.2.7 Support of Signalling Parameter "Request and Indication" 157
5.1.2.8 VPI/VPCI/VCI Support 157
5.1.2.9 Support of a Single Signalling Virtual Channel 158
5.1.2.10 Support of Error Recovery 158
5.1.2.11 Support of Public UNI and Private UNI ATM Addressing 158
5.1.2.12 Support of a Client Registration Mechanism 158
5.1.2.13 Support of End-to-end Compatibility Parameter Identification 159
5.1.2.14 Support of Multicast Service Addresses 159
5.1.3 Addressing 159
5.1.3.1 Private Networks 159
5.1.3.1.1 Authority and Format Identifier (AFI) 161
5.1.3.1.1.1 Data Country Code (DCC) 161
5.1.3.1.1.2 International Code Designator (ICD) 162
5.1.3.1.1.3 E.164 (E.164) 162
5.1.3.1.2 Domain Specific Part (DSP) 162
5.1.3.1.2.1 HO-DSP 162
5.1.3.1.2.2 End System Identifier (ESI) 162
5.1.3.1.2.2 Selector 162
5.1.3.2 Public Networks 163
5.2 Overview of Call Control 163
5.2.1 ATM Call States 163
5.2.1.1 Call States at the User Side of the Interface 164
5.2.1.1.1 Null (U0) 164
5.2.1.1.2 Call Initiated (U1) 164
5.2.1.1.3 Outgoing Call Proceeding (U3) 164

5.2.1.1.4 Call Delivered (U4) 164
5.2.1.1.5 Call Present (U6) 164
5.2.1.1.6 Call Received (U7) 164
5.2.1.1.7 Connect Request (U8) 164
5.2.1.1.8 Incoming Call Proceeding (U9) 164
5.2.1.1.9 Active (U10) 164
5.2.1.1.10 Release Request (U11) 165
5.2.1.1.11 Release Indication (U12) 165
5.2.1.2 Call States at the Network Side of the Interface 165
5.2.1.2.1 Null (N0) 165
5.2.1.2.2 Call Initiated (N1) 165
5.2.1.2.3 Outgoing Call Proceeding (N3) 165
5.2.1.2.4 Call Delivered (N4) 165
5.2.1.2.5 Call Present (N6) 165
5.2.1.2.6 Call Received (N7) 165
5.2.1.2.7 Connect Request (N8) 165
5.2.1.2.8 Incoming Call Proceeding (N9) 165
5.2.1.2.9 Active (N10) 166
5.2.1.2.10 Release Request (N11) 166
5.2.1.2.11 Release Indication (N12) 166
5.2.1.2.12 Call Abort (N22) 166
5.2.2 ATM Call States Relating to Interworking Requirements 166
5.2.3 States Associated with the Global Call Reference 166
5.2.3.1 Call States at the User Side of the Interface 166
5.2.3.1.1 Null (Rest 0) 166
5.2.3.1.2 Restart Request (Rest 1) 166
5.2.3.1.3 Restart (Rest 2) 166
5.2.3.2 Call States at the Network Side of the Interface 167
5.2.3.2.1 Null (Rest 0) 167
5.2.3.2.2 Restart Request (Rest 1) 167
5.2.3.2.3 Restart (Rest 2) 167
5.3 Message Functional Definitions and Contents 167
5.3.1 Messages for ATM point-to-point call and connection control 168
5.3.1.1 ALERTING 168
5.3.1.2 CALL PROCEEDING 169
5.3.1.3 CONNECT 170
5.3.1.4 CONNECT ACKNOWLEDGE 171
5.3.1.5 RELEASE 171
5.3.1.6 RELEASE COMPLETE 172
5.3.1.7 SETUP 173
5.3.1.8 STATUS 175
5.3.1.9 STATUS ENQUIRY 176
5.3.2 Messages for the Support of 64 kbit/s based ISDN Circuit Mode Services 176
5.3.3 Messages Related to Release 1 Supplementary Services 176
5.3.4 Messages Used with the Global Call Reference 176

5.3.4.1 RESTART 177
5.3.4.2 RESTART ACKNOWLEDGE 178
5.3.5 Messages for Point-to-multipoint call and connection control 178
5.3.5.1 ADD PARTY 179
5.3.5.2 ADD PARTY ACKNOWLEDGE 181
5.3.5.3 ADD PARTY REJECT 181
5.3.5.4 DROP PARTY 182
5.3.5.5 DROP PARTY ACKNOWLEDGE 182
5.4 General Message Format and Information Element Coding 183
5.4.1 Overview 183
5.4.2 Protocol Discriminator 184
5.4.3 Call Reference 185
5.4.4 Message Type and Message Length 187
5.4.4.1 Message Type 187
5.4.4.2 Message Length 189
5.4.5 Variable Length Information Elements 189
5.4.5.1 Coding Rules 189
5.4.5.2 Extension of Codesets 195
5.4.5.3 Broadband Locking Shift Procedures 195
5.4.5.4 Broadband Non-Locking Shift Procedures 195
5.4.5.5 ATM Adaptation Layer Parameters 196
5.4.5.6 ATM Traffic Descriptor 203
5.4.5.7 Broadband Bearer Capability 209
5.4.5.8 Broadband High Layer Information 211
5.4.5.9 Broadband Low Layer Information 212
5.4.5.10 Call State 218
5.4.5.11 Called Party Number 219
5.4.5.12 Called Party Subaddress 220
5.4.5.13 Calling Party Number 222
5.4.5.14 Calling Party Subaddress 224
5.4.5.15 Cause 225
5.4.5.16 Connection Identifier 231
5.4.5.17 End-to-End Transit Delay 232
5.4.5.18 Quality of Service Parameter 233
5.4.5.19 Broadband Repeat Indicator 234
5.4.5.20 Restart Indicator 236
5.4.5.21 Broadband Sending Complete 237
5.4.5.22 Transit Network Selection 238
5.4.6 Information Elements for Interworking with 64 kbit/s Based ISDN 239
5.4.7 Information Elements for Supplementary Services 239
5.4.8 ATM Forum Specified Information Elements 239
5.4.8.1 Endpoint Reference 239
5.4.8.2 Endpoint State 240
5.5 Call/Connection Control Procedures For ATM Point-to-Point Calls 241
5.5.1 Call/Connection establishment at the originating interface 242

5.5.1.1 Call/Connection request 242
5.5.1.2 Connection Identifier (VPCI/VCI) Allocation/Selection 242
5.5.1.2.1 Connection Identifier Allocation/Selection - Origination 242
5.5.1.2.2 Use of VPCIs 243
5.5.1.2.3 VPCI and VCI Ranges 243
5.5.1.3 QoS and Traffic parameters selection procedures 243
5.5.1.4 Invalid Call/Connection control information 244
5.5.1.5 Call/Connection proceeding 244
5.5.1.6 Call/Connection confirmation indication 245
5.5.1.7 Call/Connection acceptance 245
5.5.1.8 Call/Connection rejection 245
5.5.1.9 Transit network selection 245
5.5.1.10 Extensions for symmetric call operation 245
5.5.2 Call/Connection establishment at the destination interface - Point-to-Point Access Configuration Call Offering 245
5.5.2.1 Incoming Call/Connection request 245
5.5.2.2 Address and Compatibility Check 246
5.5.2.3 Connection identifier (VPCI/VCI) allocation/selection — destination 246
5.5.2.4 QoS and Traffic parameter selection procedures 246
5.5.2.5 Call/Connection confirmation 247
5.5.2.5.1 Response to SETUP 247
5.5.2.5.1.1 Procedures when the User is an ATM endpoint 247
5.5.2.5.1.2 Procedures when the User is not an ATM endpoint 247
5.5.2.5.2 Receipt of CALL PROCEEDING 247
5.5.2.5.3 Called user clearing during incoming call establishment 247
5.5.2.5.4 Call failure 248
5.5.2.6 Call/Connection acceptance 248
5.5.2.7 Active indication 248
5.5.3 Call/Connection establishment at the destination — Point-to-multipoint access arrangement call offering 248
5.5.4 Call/Connection clearing 248
5.5.4.1 Terminology 249
5.5.4.2 Exception conditions 249
5.5.4.3 Clearing initiated by the user 249
5.5.4.4 Clearing initiated by the network 250
5.5.4.5 Clear collision 250
5.5.5 Restart procedure 250
5.5.5.1 Sending RESTART 251
5.5.5.2 Receipt of RESTART 252
5.5.6 Handling of error conditions 253
5.5.6.1 Protocol discrimination error 253
5.5.6.2 Message too short 253
5.5.6.3 Call reference error 253
5.5.6.3.1 Invalid call reference format 253

5.5.6.3.2 Call reference procedural errors 254
5.5.6.4 Message type or message sequence errors 254
5.5.6.5 Message length error 255
5.5.6.6 General information element errors 255
5.5.6.6.1 Information element sequence 255
5.5.6.6.2 Duplicated information elements 255
5.5.6.6.3 Coding standard error 255
5.5.6.7 Mandatory information element error 256
5.5.6.7.1 Mandatory information element missing 256
5.5.6.7.2 Mandatory information element content error 256
5.5.6.8 Non-mandatory information element errors 257
5.5.6.8.1 Unrecognized information element 257
5.5.6.8.2 Non-mandatory information element content error 258
5.5.6.8.3 Unexpected recognized information element 258
5.5.6.9 Signalling AAL reset 258
5.5.6.10 Signalling AAL failure 259
5.5.6.11 Status enquiry procedure 259
5.5.6.12 Receiving a STATUS message 260
5.5.7 Forward Compatibility Procedures 261
5.6 Call/Connection Control Procedures for Point-to-Multipoint Calls 261
5.6.1 Adding a party at the originating interface 263
5.6.1.1 Set up of the first party 263
5.6.1.2 Adding a Party 264
5.6.1.3 Invalid Call/Connection Control Information or Service Request in the ADD PARTY message 265
5.6.1.4 Add Party Received 266
5.6.1.5 Add Party Connected 266
5.6.1.6 Add Party Rejection 266
5.6.2 Add party establishment at the destination interface 266
5.6.2.1 Incoming add party request 266
5.6.2.2 Address and compatibility check 267
5.6.2.3 Connection identifier (VPCI/VCI) allocation/selection — destination 267
5.6.2.4 QoS and Traffic parameter selection procedures 268
5.6.2.5 Call/Connection confirmation 268
5.6.2.5.1 Response to ADD PARTY 268
5.6.2.5.1.1 Procedures when the user is an ATM endpoint 268
5.6.2.5.1.2 Procedures when the user is not an ATM endpoint 268
5.6.2.5.2 Called user rejection of incoming call establishment 269
5.6.2.5.3 Call failure 269
5.6.2.6 Call/Connection accept 269
5.6.2.7 Active indication 269
5.6.3 Party clearing 269
5.6.3.1 Terminology 269
5.6.3.2 Exception conditions 269

5.6.3.3 Dropping a party initiated by the user 270
5.6.3.4 Dropping a party initiated by the network 271
5.6.3.4.1 Clearing with a DROP PARTY message 272
5.6.3.5 Clear collision 273
5.6.4 Restart Procedure 273
5.6.5 Handling of error conditions 273
5.6.5.1 Protocol Discriminator Error 274
5.6.5.2 Message too short 274
5.6.5.3 Call reference and Endpoint Reference errors 274
5.6.5.3.1 Call reference procedural errors 274
5.6.5.3.2 Endpoint reference error 274
5.6.5.3.2.1 Invalid endpoint reference format 274
5.6.5.3.2.2 Endpoint reference procedural errors 274
5.6.5.4 Message type or message sequence errors 275
5.6.5.5 Message length errors 275
5.6.5.6 General Information Element errors 275
5.6.5.7 Mandatory information element error 275
5.6.5.7.1 Mandatory information element missing 275
5.6.5.7.2 Mandatory information element content error 276
5.6.5.8 Non-mandatory information element errors 276
5.6.5.8.1 Unrecognized information element 276
5.6.5.9 Signalling AAL reset 277
5.6.5.10 Signalling AAL failure 277
5.6.5.11 Status enquiry procedure 277
5.6.5.12 Receiving a STATUS message 278
5.7 List of Timers 280
5.7.1 Timers in the Network Side 280
5.7.2 Timers in the User Side 282
5.8 Address Registration 284
5.8.1 Overview 284
5.8.2 Capabilities 285
5.8.2.1 Initialization-time Exchange of Addressing Information 285
5.8.2.2 Restrictions on Network-Prefix/User-Part Combinations 285
5.8.2.3 Rejection of Unacceptable Values 285
5.8.2.4 Dynamic Addition/Deletion 286
5.8.2.5 De-registration on UNI “link down” Condition. 286
5.8.3 General Description of Procedures 286
5.8.4 Management Information Base for Address Registration 287
5.8.4.1 Prefix Group (CR) 287
5.8.4.1.1 Network Prefix 287
5.8.4.1.2 Network Prefix Status 287
5.8.4.2 Address Group (CR) 287
5.8.4.2.1 ATM Address 287
5.8.4.2.2 ATM Address Status 287
5.8.5 Address Registration Procedures 288

5.8.5.1 Network-Side UME 288
5.8.5.2 User-Side UME 289
5.8.5.3 Retransmission of SetRequest Messages 290
5.8.6 MIB Definition 290
5.9 Signalling ATM Adaptation Layer (SAAL) 294

References 297

Annex A: Guidelines for Use of ATM Address Formats 300

Annex B: Compatibility Checking 303

Annex C: B-LLI Negotiation 304
C.1 General 304
C.2 B-LLI notification to the called user. 304
C.3 B-LLI negotiation between users 304
C.4 Alternate requested values 305

Annex D: Transit Network Selection 306
D.1 Selection not supported 306
D.2 Selection supported 306

Annex E: Cause Definitions 307

Annex F: ATM Adaptation Layer Parameters Negotiation 312
F.1 General 312
F.2 ATM adaptation layer parameter indication in the SETUP message 312
F.3 Maximum CPCS-SDU Size negotiation 313
F.4 MID range negotiation 314
F.5 Use of Forward and Backward Maximum CPCS-SDU Size by the AAL entity in the user plane 314

Appendix: A Quality of Service Guidelines 316
A.1 Introduction 316
A.1.1 Objective 316
A.1.2 Approach 316
A.1.3 Terminology 317
A.1.3.1 Cell Event 317
A.1.3.2 ATM Cell Transfer Outcome 317
A.2 QoS Reference Configuration 318
A.3 ATM Performance Parameters 320
A.3.1 Cell Error Parameters 320
A.3.1.1 Cell Error Ratio 320
A.3.1.2 Severely-Errored Cell Block Ratio 320
A.3.2 Cell Loss Ratio 321

A.3.3 Cell Misinsertion Rate 321
A.3.4 Cell Transfer Delay 321
A.3.4.1 Mean Cell Transfer Delay 321
A.3.4.2 Cell Delay Variation (CDV) 322
A.3.4.2.1 1-Point CDV 322
A.3.4.2.2 2-Point CDV 322
A.3.5 Quality of Service provided by the ATM Layer 322
A.4 QoS Classes 323
A.4.1 Specified QoS Classes 323
A.4.2 Unspecified QoS Class 324
A.5 Measurement Methods 325
A.5.1 Cell Error Parameters 325
A.5.1.1 Cell Error Ratio 325
A.5.1.2 Severely Errored Cell Block Ratio 325
A.5.2 Cell Loss Ratio 325
A.5.3 Cell Misinsertion Rate 326
A.5.4 Cell Transfer Delay 326
A.5.5 Measuring Cell Non Conformance Ratio 326
A.5.6 Measuring of Range of Cell Transfer Delay 327
A.6 Factors Affecting ATM QoS Performance Parameters 329
A.6.1 Sources of QoS Degradation 329
A.6.1.1 Propagation Delay 329
A.6.1.2 Media Error Statistics 329
A.6.1.3 Switch Architecture 329
A.6.1.4 Buffer Capacity 329
A.6.1.5 Traffic Load 329
A.6.1.6 Number of Nodes in Tandem 329
A.6.1.7 Resource Allocation 330
A.6.1.8 Failures 330
A.6.2 Impact of QoS Degradation on Performance Parameters 330
A.6.2.1 Cell Error Ratio and Severely Errored Cell Block Ratio 330
A.6.2.2 Cell Loss Ratio 330
A.6.2.3 Cell Misinsertion Rate 331
A.6.2.4 Cell Transfer Delay 331
A.6.2.4.1 Mean Cell Transfer Delay 331
A.6.2.4.2 Cell Delay Variation (CDV) 332
A.6.2.5 Degradation of QoS Parameters Summary 333
A.6.3 Principles of Allocation 333

Appendix B: Conformance Examples in a Traffic Contract 334
B.1 Introduction 334
B.2 Example 1 Switched Multi-megabit Data Service (SMDS)[31] 335
B.3 Example 2a Frame Relay Service (FRS)[32] 336
B.4 Example 2b Frame Relay Service (FRS) 339

B.5 Example 3 Constant Bit Rate Services 340
B.6 Example 4 LAN Interconnection 341

Appendix C: Point-to-Multipoint Signalling Procedures Using Separate State Machines (Informative) 342
C.1 Introduction 342
C.2 Description of the Separate State Machines 342
C.2.1 Control Model 342
C.2.2 Party States and Link States 344
C.2.3 Primitives between the Multi-Party Control and the Link Control 344
C.2.4 Primitives between Point-to-Multipoint Control and Coordination Function 344
C.3. Information Flows for Point-to-Multipoint Communication 345
C.3.1 Functional Blocks used for the Description of Information Flows 345
C.3.2 Information Flows for the Successful Adding of a Party to an already Existing Call 346
C.3.2.1 Overall Description of Information Flows 346
C.3.2.2 Primitives between Point-toMultipoint Control and Link Control and between Coordination Function and Point-toMultipoint Control 347
C.3.2.3 Functional Entity Actions (FEAs) 348
C.3.3 Dropping of a Party from an Existing Point-to-Multipoint Call by the Root. 354
C.3.3.1 Overall Description of Information Flows 354
C.3.3.2 Primitives between Point-to-Multipoint Control and Link Control. 355
C.3.3.3 Functional Entity Actions (FEAs) 355

Appendix D: Example Signalling Codings 359
D.1 ATM Adaptation Layer Parameters 359
D.1.1 Example of information element coding for AAL 1 359
D.1.2 Example of information element coding for AAL 5 361
D.2 Broadband Bearer Capability 362
D.2.1 Example of information element coding for variable bit rate, connection oriented service with no timing requirements 362
D.3 Broadband Low Layer Information 363
D.3.1 Example of information element coding for multiprotocol interconnect using the LLC encapsulation 363
D.3.2 Example of information element coding for transport of IP datagrams using the "Null encapsulation" over AAL 5 364
D.3.3 Example of information element coding for transport of bridged frames using the "Null encapsulation" over AAL 5 365

Appendix E: Differences with ITU-T draft Recommendation Q.2931 363

Appendix F: Guidelines on the use of Bearer Class, Traffic Parameters and QoS 386
F.1 Bearer Class 386
F.1.1 BCOB-A 386
F.1.2 BCOB-C 386
F.1.3 BCOB-X 386
F.2 Allowed Combination of Bearer Capabilities, Traffic Parameters, and QoS 386

Appendix G: OAM Cell Error Detection Code Field 388

Appendix H: Glossary 389

List of Figures

Figure 1-1 Implementations of the ATM UNI 3
Figure 1-2 ATM Bearer Service Attributes 7
Figure 1-3 User-Network Interfaces Configuration 8
Figure 1-4 B-ISDN Protocol Reference Model 9
Figure 2-1 Physical Layer Functions (U-plane) 13
Figure 2-2 SONET STS-3c at the UNI 17
Figure 2-3 SONET Overhead Bytes at the UNI 18
Figure 2-4 Physical Layer Management at the UNI 19
Figure 2-5a SONET Physical Layer OAM flow 20
Figure 2-5b Example of OAM flow at the UNI 21
Figure 2-6 Physical Layer Functions 23
Figure 2-7 DS3 PLCP Frame (125 us) 24
Figure 2-8 Cycle/Stuff Counter Definition 26
Figure 2-9 PLCP Path Status (G1) Definition 26
Figure 2-10 POI Code Definition 27
Figure 2-11 Physical Layer Functions (U-plane) 29
Figure 2-12 Local Fiber Link 30
Figure 2-13 ATM Access Link Control Code Summary 31
Figure 2-14 HEC Verification Flow 33
Figure 2-15 Physical Layer Functions (U-plane) 34
Figure 2-16 Chromatic Dispersion Requirements 36
Figure 2-17 AOI Optical Transmit Parameters 37
Figure 2-18 MMF Eye Diagram for the Transmitter 38
Figure 2-19 AII Optical Receive Parameters 39
Figure 2-20 Pin Assignment and Data Connector Detail 41
Figure 2-21 AOI Electrical Transmit Parameters 42
Figure 2-22 AOI Electrical Transmit Pulse Envelope 42
Figure 2-23 AII Electrical Receive Parameters 43
Figure 2-24 Physical Layer Frame Format 44
Figure 2-25 Byte 6 Definition 44
Figure 2-26 Synchronization Symbols 44
Figure 2-27 HEC Verification Flow 46
Figure 3-1 ATM Service Access Point (SAP) Primitives 50
Figure 3-2 ATM-SAP Parameters 51
Figure 3-3 PHY-SAP Services Required by the ATM Layer 52
Figure 3-4 ATM Cell Structure at the UNI 53
Figure 3-5 ATM Field Encoding Covention 53
Figure 3-6 Functions supported at the UNI (U-plane) 55
Figure 3-7 Pre-Defined Header Field Values 57
Figure 3-8 Default Header Field Value 58
Figure 3-9 Payload Type Indicator Encoding 59

Figure 3-10 ATM Layer Management Functions at the UNI 61
Figure 3-11 ATM Layer OAM flows at the UNI 62
Figure 3-12a Common OAM Cell Format 64
Figure 3-12b OAM Cell Fault Management-Specific Fields 65
Figure 3-13 Loopback Function 68
Figure 3-14 Procedures Used to Set Values of Traffic Contract Parameters 75
Figure 3-15 Equivalent versions of the Generic Cell Rate Algorithm 79
Figure 3-16 PCR Reference Model 81
Figure 3-17 Ideal Cell Arrival at the Public UNI (t = 0.5d) 84
Figure 3-18 Possible Cell Arrival at the Public UNI (t = 1.5d) 84
Figure 3-19 Possible Cell Arrival at the Public UNI (t = 3.5d) 84
Figure 3-20 Possible Cell Arrival at the Public UNI (t = 7d) 84
Figure 3-21 SCR and Burst Tolerance Reference Model 85
Figure 3-22 Mapping Cell Loss Ratios for VCC and VPC 93
Figure 3-23 Location of the UPC Functions 98
Figure 4-1 Definition and Context of ILMI 106
Figure 4-2 Examples of Equipment Implmenting the ATM UNI ILMI 109
Figure 4-3 ILMI ATM UNI MIB Tree Structure 111
Figure 5-1a DCC ATM Format 160
Figure 5-1b ICD ATM Format 160
Figure 5-1c E.164 ATM Format 160
Figure 5-2 CALL PROCEEDING Message Contents 168
Figure 5-3 CONNECT Message Contents 170
Figure 5-4 CONNECT ACKNOWLEDGE Message Contents 171
Figure 5-5 RELEASE message content 171
Figure 5-6 RELEASE COMPLETE message content 172
Figure 5-7 SETUP message content 174
Figure 5-8 STATUS message content 175
Figure 5-9 STATUS ENQUIRY message content 176
Figure 5-10 RESTART message content 177
Figure 5-11 RESTART ACKNOWLEDGE message content 178
Figure 5-12 ADD PARTY message content 179
Figure 5-13 ADD PARTY ACKNOWLEDGE message content 181
Figure 5-14 ADD PARTY REJECT message content 181
Figure 5-15 DROP PARTY message content 182
Figure 5-16 DROP PARTY ACKNOWLEDGE message content 182
Figure 5-17 General Message Organization Example 183
Figure 5-18 Protocol Discriminator 184
Figure 5-19 Call Reference Information Element 186
Figure 5-20a Encoding for Global Call Reference 187
Figure 5-20b Encoding of the Dummy Call Reference 187
Figure 5-21 Message Type 187
Figure 5-22 Message Length 189

Figure 5-23 General Information Element Format 193
Figure 5-24 ATM Adaptation Layer Parameters Information Element (For all AAL Types) 196
Figure 5-25 ATM Adaptation Layer Parameters Information Element (Octet Groups 6-12 for AAL Type 1) 197
Figure 5-26 ATM Adaptation Layer Parameters Information Element (Octet Groups 6-10 for AAL Type 3/4) 198
Figure 5-27 ATM Adaptation Layer Parameters Information Element (Octet Groups 6-9 for AAL Type 5) 199
Figure 5-28 ATM Adaptation Layer Parameters Information Element (Octet Group 6 for User Defined AAL) 199
Figure 5-29 ATM Traffic Descriptor Information Element 205
Figure 5-30 Broadband Bearer Capability Information Element 209
Figure 5-31 Broadband High Layer Information Information Element 211
Figure 5-32 Broadband Low Layer Information Information Element 214
Figure 5-33 Call State Information Element 218
Figure 5-34 Called Party Number Information Element 219
Figure 5-35 Called Party Subaddress Information Element 221
Figure 5-36 Calling Party Number Information Element 222
Figure 5-37 Calling Party Subaddress Information Element 224
Figure 5-38 Cause Information Element 226
Figure 5-39 Connection Identifier Information Element 231
Figure 5-40 Quality of Service parameter Information Element 233
Figure 5-41 Broadband Repeat Indicator Information Element 235
Figure 5-42 Restart Indicator Information Element 236
Figure 5-43 Broadband Sending Complete Information Element 237
Figure 5-44 Transit Network Selection Information Element 238
Figure 5-45 Endpoint Reference Information Element 239
Figure 5-46 Endpoint State Information Element 240
Figure 5-47 SAAL Structure 296
Figure A-1 ATM QoS Reference Configuration 319
Figure A-2 Estimation of 2-point CDV from 1-point CDV for Connections providing CBR service 328
Figure A-3 Degradation of QoS Parameters 333
Figure B-1 Example 1 336
Figure B-2 Example 2a 338
Figure B-3 Example 2b 340
Figure B-4 Example 3 341
Figure C-1 Control Model with Separated State Machines 342
Figure C-2 State Machines of a Network involved in a Point-to-Multipoint Call 343
Figure C-3 Functional Blocks of a Point-to-Multipoint Call 346
Figure C-4 Information Flows for Successful Adding of a New Party 347
Figure C-5 Information Flows for a Local Acknowledgement of DROP PARTY 354

List of Tables

Table 5-1 Reference Configurations 153

Table 5-2 Messages for ATM Call and Connection Control 168

Table 5-3 Messages Used with the Global Call Reference 176

Table 5-4 Messages Used with ATM Point-to-multipoint call and connection control 178

Table 5-5 Information Element Identifier Coding (Codeset 0) 192

Table 5-6 General Information Element Format 193

Table 5-7 Allowable Combinations of Traffic Parameters in a Given Direction 208

Table 5-8 Combination of Traffic Parameters for Best Effort 208

Table 5-9 Timers in the network side 280

Table 5-10 Timers in the user side 282

Table C-1 Primitives Used between Link Control and Point-to-Multipoint Control 344

Table F-1 Allowable Combinations of Traffic Related Parameters in the SETUP message 387