

Measure, measure, measure: BRDF, BTF, Light Fields

Lecture #6

Appearance Modeling, Fall 2005

Srinivasa Narasimhan

Thanks to Steve Marschner, Shree Nayar, Ravi Ramamoorthi,
Marc Levoy, Pat Hanrahan, Kristin Dana, Ken Perlin, Debevec, Matusik

Measuring BRDFs

Why bother modeling BRDFs?


Why not directly measure BRDFs?

- True knowledge of surface properties
- Accurate models for graphics


Measuring BRDFs

- A full BRDF is 4-dimensional
- Simpler measurements (0D/1D/2D/3D) often useful
- Lets start with simplest and get more complex

Measuring Reflectance




$0^\circ/45^\circ$
Diffuse Measurement



$45^\circ/45^\circ$
Specular Measurement

Integrating Spheres

- Sphere with diffuse material on inside
- Geometry ensures even illumination
- More accurate measure of diffuse reflectance
- Remember the white-out condition!




Gloss Measurements

- Standardized for applications such as paint manufacturing
- Example: “contrast gloss” is essentially ratio of specular to diffuse
- “Sheen” is specular measurement at 85°


Gloss Measurements

- “Haze” and “distinctness of image” are measurements of width of specular peak




BRDF Measurements

- Next step up in complexity: measure BRDF in plane of incidence (1- or 2-D)




Gonioreflectometers

- Three degrees of freedom spread among light source, detector, and/or sample



Gonioreflectometers

- Three degrees of freedom spread among light source, detector, and/or sample



Gonioreflectometers

- Can add fourth degree of freedom to measure anisotropic BRDFs





Image-Based BRDF Measurement

- Reduce acquisition time by obtaining larger (e.g. 2-D) slices of BRDF at once
- Idea: Camera can acquire 2D image
- Requires mapping of angles of light to camera pixels

Ward's BRDF Measurement Setup

- Collect reflected light with hemispherical mirror



Ward's BRDF Measurement Setup

- Result: each image captures light at all exitant angles



Image-Based BRDF Measurement

- For uniform BRDF, capture 2-D slice corresponding to variations in normals (Marschner et al)






Image-Based BRDF Measurement

- Any object with known geometry





Image-based measurement of skin





SIGGRAPH2005

Measurement

- Light Source
 - Hamamatsu SQ Xenon lamp
 - Stable emission output
 - Continuous and relatively constant radiation spectrum





SIGGRAPH2005

Measurement

- Turntable
 - Kaidan MD-19
 - Computer-controlled
- Dark Room
 - Walls painted with flat black paint
- Spherical Samples





SIGGRAPH2005

Calibration

- Geometric calibration
 - Contact digitizer
 - Faro Arm
 - Intrinsic & extrinsic camera parameters
 - Sphere center & radius
 - Light Position
 - parameterized on a circle in 3D






SIGGRAPH2005

Measurement

- 20-80 million reflectance measurements per material
- Each tabulated BRDF entails $90 \times 90 \times 180 \times 3 = 4,374,000$ measurement bins





SIGGRAPH2005

Rendering from Tabulated BRDFs

- These BRDFs are immediately useful
- Direct renderings from measurements



Nickel

Hematite


Gold Paint

Pink Felt



SIGGRAPH2005

Measurement Process










SIGGRAPH2005

Linear Combinations of BRDFs (LCB)

- Can we find a linear combination of our existing BRDFs that match any new one?
- Requires only estimating 100 coefficients for source BRDFs
- Compute a set of 800 constraints that allow estimating these 100 coefficients robustly


$$\alpha_1 \text{  + \alpha_2 \text{  + \alpha_3 \text{  + \alpha_4 \text{  + \dots = \text{ $$



SIGGRAPH2005

BRDFs as Vectors in High Dimensional Space



- Each tabulated BRDF is a vector in $90 \times 90 \times 180 \times 3 = 4,374,000$ dimensional space





Linear Analysis (PCA)

- Find optimal linear basis for our data set
- 45 components needed to reduce residue to under measurement error



mean

5

10

20

30

45

60

all



SIGGRAPH2005

Navigation Results



Adding Silver Trait



SIGGRAPH2005

Navigation Results



Adding Specular Trait

Navigation Results



SIGGRAPH2005



Adding Metallic Trait

Representing Physical Processes



SIGGRAPH2005



Steel Oxidation

Next Step in the Appearance Food Chain

Textures

Spatially Varying BRDFs

CURET Database – [Dana, Nayar 96]

Next Step in the Appearance Food Chain

Why bother about measuring patches or spheres?

Why not measure the scenes themselves directly?

- Change only lighting (for Relighting)
- Change only viewpoint (Light Fields)
- Change both lighting and view point



Debevec et al. Siggraph 2000



VIDEO and DEMO for relighting

Next Step in the Appearance Food Chain

- Capture Light Fields directly by changing viewpoint

Levoy & Hanrahan, Gortler et al., Siggraph 96

See great presentation on the Graphics Lab website at Stanford.

Can we measure our way out of misery?

- WYSIWYG – 😊
- WYSIAYG - 😞

Dimensionality of Appearance

$$(x, y, t, \theta, \phi, \lambda)_{in} \rightarrow (x, y, t, \theta, \phi, \lambda)_{out}$$

General function = 12D

↓ Assume time doesn't matter (no phosphorescence)
↓ Assume wavelengths are equal (no fluorescence, raman scattering)

Scattering function = 9D

↓ Assume wavelength is discretized or integrated into RGB
(This is a common assumption for computer graphics)

Single-wavelength Scattering function = 8D

$$(x, y, \theta, \phi)_{in} \rightarrow (x, y, \theta, \phi)_{out}$$

$$(x, y, \theta, \phi)_{in} \rightarrow (x, y, \theta, \phi)_{out}$$

Single-wavelength Scattering function = 8D

Ignore subsurface scattering $(x, y)_{in} = (x, y)_{out}$

Ignore dependence on position

Bidirectional Texture Function (BTF)
Spatially-varying BRDF (SVBRDF) = 6D

Bidirectional Subsurface Scattering
Distribution Function (BSSRDF) = 6D

Ignore direction of incident light

Ignore dependence on position

Ignore subsurface scattering

Light Fields, Surface LFs = 4D

$$(x, y, \theta, \phi)_{out}$$

BRDF = 4D

$$(\theta, \phi)_{in} \rightarrow (\theta, \phi)_{out}$$

Assume Lambertian

Assume isotropy

Texture Maps = 2D

$$(x, y)_{out}$$

3D

Measure plane of incidence

2D

Low-parameter BRDF model

0D