



15-441 15-641 Computer Networking

Virtual Circuits, MPLS, VLANs
Peter Steenkiste

Fall 2014

www.cs.cmu.edu/~prs/15-441-F14

Announcements



- Extra office hours – see the web
- Sample midterm on the web
 - The real midterm will be different

2

Outline




- Circuit switching refresher
- Virtual Circuits - general
 - Why virtual circuits?
 - How virtual circuits? -- tag switching!
- Two modern implementations
 - ATM - teleco-style virtual circuits
 - MPLS - IP-style virtual circuits
- Virtual LANs
 - How do they differ?


Circuit Switching



- Source first establishes a connection (circuit) to the destination.
 - Each router or switch along the way may reserve some bandwidth for the data flow
- Source sends the data over the circuit.
 - No destination address needed - routers know the path
- The connection is torn down.
- Example: traditional telephone network.



Circuit Switching



- Switch remembers how to forward data
 - No addresses!
- Many options
 - Between specific wires (circuit = wire)
 - Between timeslots (TDMA on each wire)
 - Between frequencies (FDMA on each wire)

Circuit Versus Packet Switching



Circuit Switching

- Fast switches can be built relatively inexpensively
- Inefficient for bursty data
- Predictable performance (e.g. hard QoS)
- Requires circuit establishment before communication

Packet Switching


- Switch design is more complex and expensive
- Allows statistical multiplexing
- Difficult to provide QoS guarantees
- Data can be sent without signaling delay and overhead

Can we get the benefits of both?

Virtual Circuits



- Each wire carries many “virtual” circuits.
- Forwarding based on virtual circuit (VC) identifier
 - IP header: src, dst, etc.
 - Virtual circuit header: just “VC”
 - A path through the network is set up when the VC is established
 - Can use statistical multiplexing for efficiency
- Can support wide range of quality of service.
 - No guarantees: best effort service
 - Weak guarantees: delay < 300 msec, ...
 - Strong guarantees: e.g. equivalent of physical circuit




Virtual Circuits Versus Packet Switching



- Many similarities:
 - Forwarding based on “address” (VCID or dest address)
 - Statistical multiplexing for efficiency
 - Must have buffers space on switches
- Virtual circuit switching:
 - Uses short connection identifiers to forward packets
 - Switches know about the connections so they can more easily implement features such as quality of service
 - Switches are stateful: VC state cannot be lost
- Packet switching:
 - Use full destination addresses for forwarding packets
 - Can send data right away: no need to establish a connection first
 - Switches are stateless: easier to recover from failures
 - Adding QoS is hard

Virtual Circuit Forwarding




Address	Next Hop
VC1	3
VC2	3
VC3	4
VC4	?
VC5	?

- Address used for look up is a virtual circuit identifier (VC id)
- Forwarding table entries are filled in during signaling
- VC id is often shorter than destination address

9

VC versus Packets: Control over Path



R1 VC table:

VC 1 R2


VC 2 R3

R1 packet forwarding table:

Dst R2

Different paths to same destination!
(useful for traffic engineering!)


How to Pick a VC Id?



- When B establishes green virtual circuit, how does it know what VC ids are available?
- Even worse: every VC id may already be used on a link along the path to the destination
- Solution: VC id swapping

11

VC id Swapping



Address	Next Hop	Next id
VC1 = 1	3	2
VC2 = 2	3	3
VC3 = 1	4	1
VC4 = 2	3	1

- Look up is based on VC id in header + incoming port number
- Forwarding table specifies outgoing port and new VC id
- VC id conflicts can be resolved locally during signaling


12

Connections and Signaling



- Permanent vs. switched virtual connections (PVC/SVC)
 - static vs. dynamic. PVCs last “a long time”
 - E.g., connect two bank locations with a PVC
 - SVCs are more like a phone call
 - PVCs administratively configured (but not “manually”)
 - SVCs dynamically set up on a “per-call” basis
- Topology
 - point to point, point to multipoint, multipoint to multipoint
- Challenges: How to configure these things?
 - What VCI to use?
 - Setting up the path

SVC Connection Setup



Virtual Circuits In Practice



- Asynchronous Transfer Mode - ATM: Teleco approach
 - Kitchen sink. Based on voice, support file transfer, video, etc., etc.
 - Intended as IP replacement. That didn't happen. :)
 - Today: rarely used.
- MPLS: The “IP Heads” answer to ATM
 - Stole good ideas from ATM
 - Integrates well with IP
 - Today: Used inside many transit networks to provide traffic engineering, VPN support, simplify core.
- Other networks just run IP.
- Older tech: Frame Relay
 - Only provided PVCs. Used for quasi-dedicated 56k/T1 links between offices, etc. Slower, less flexible than ATM.

Outline



- Circuit switching refresher
- Virtual Circuits - general
 - Why virtual circuits?
 - How virtual circuits? -- tag switching!
- Two modern implementations
 - ATM - teleco-style virtual circuits
 - MPLS - IP-style virtual circuits
- Virtual LANs
 - How do they differ?

ATM History



- Telephone companies supported voice telephony: 4 kHz analog, 64 kbs digital
- They provided lines for data networking
 - ISDN: 64 kbps and faster channels
 - T1 (1.544 Mbps)
 - T3 (44.736 Mbps)
- Wanted to become the primary service provider for data networking services
 - file transfer: bursty, many Mbps peak
 - database access: bursty, low latency
 - Multimedia: synchronized
 - Video: 6 MHz analog, 1.2-200 Mbps digital

Cell Switching




- Small, fixed-size cells
[Fixed-length data][header]
- Why?
 - Voice only needs small “packets”
 - Efficiency: All packets the same
 - Easier hardware parallelism, implementation
 - Switching efficiency:
 - Lookups are easy -- table index.
 - Result: Very high cell switching rates.
 - Initial ATM was 155Mbit/s.
 - Ethernet was 10Mbit/s at the same time. (!)

ATM Features



- Fixed size cells (53 bytes).
- Virtual circuit technology using hierarchical virtual circuits (VP, VC).
- PHY (physical layer) processing delineates cells by frame structure, cell header error check.
- Support for multiple traffic classes by adaptation layer.
 - E.g. voice channels, data traffic
- Elaborate signaling stack.
 - Backwards compatible with respect to the telephone standards
- Standards defined by ATM Forum.
 - Organization of manufacturers, providers, users

The ATM Cell (UNI)



IP over ATM Switched VCs



- When sending IP packets over an ATM network, set up a VC to destination.
 - ATM network can be end to end, or just a partial path
 - ATM is just another link layer
- Virtual connections can be cached.
 - After a packet has been sent, the VC is maintained so that later packets can be forwarded immediately
 - VCs eventually times out
- Properties.
 - Overhead of setting up VCs (delay for first packet)
 - Complexity of managing a pool of VCs
 - + Flexible bandwidth management
 - + Can use ATM QoS support for individual connections (with appropriate signaling support)

ATM Discussion





- Vision: ATM is a replacement for IP.
 - Could carry both traditional telephone traffic (CBR circuits) and other traffic (data, VBR)
 - Simple switching core: forwarding based on VC identifiers
 - Better than IP, since it supports QoS, traffic engineering
- Reality: Traffic engineering benefits were attractive
 - Fast VCI lookup became less critical over time
- But: Complex technology.
 - Signaling software is very complex
 - Technology did not match people's experience with IP
 - supporting connection-less service model on connection-based technology is painful
 - deploying ATM in LAN is complex (e.g. broadcast)
 - With IP over ATM, a lot of functionality is replicated

MPLS



- Multi-Protocol Label Switching
- Bringing virtual circuit concept into IP
- Driven by multiple forces
 - QoS
 - Traffic engineering
 - High performance forwarding
 - VPN




Some MPLS slides from H. Zhang

MPLS Vocabulary: LSP




- Label-switched path (LSP)
 - Simplex path through interior network



MPLS Vocabulary: LSR




- Label-switching router (LSR) performs
 - MPLS packet forwarding
 - LSP setup



MPLS Vocabulary: LER




- Label Edge Router (LER)
 - Ingress and egress node of LSP
 - Packet enters and leaves the LSP



MPLS Vocabulary: Transit




- Transit router
 - Zero or more transit routers
 - Swaps MPLS label
 - Sends traffic to next hop in LSP




MPLS Header




- IP packet is encapsulated in MPLS header and sent down LSP
- 
- IP packet is restored at end of LSP by egress router
 - TTL is adjusted, transit LSP routers count towards the TTL
 - MPLS is an optimization – does not affect IP semantics

MPLS Header




- Label
- Class of service
- Stacking bit
 - Remember me?
- Time to live
 - Decrement at each LSR, or
 - Pass through unchanged

Forwarding Equivalence Classes




- FEC = "A subset of packets that are all treated the same way by a router"
- The concept of FECs provides for a great deal of flexibility and scalability
- In conventional routing, a packet is assigned to a FEC at each hop (i.e. L3 look-up), in MPLS it is only done once at the network ingress.

LSPs Driven by Routing




- A LSP is actually part of a tree from every source to that destination (unidirectional).
- Control protocol (e.g. LDP) builds that tree using existing IP forwarding tables to route the control messages.

MPLS Builds on Standard IP




- Destination based forwarding tables as built by OSPF, IS-IS, RIP, etc.


IP Forwarding – Hop-by-Hop Control



Label Switched Path (LSP)




Explicitly Routed - ER-LSP



ER-LSP follows route that source chooses. In other words, the control message to establish the LSP (label request) is **source routed**.

Explicitly Routed LSP - Example



Protocol Comparison



	Forwarding	Control Protocols
Ethernet	Dest MAC address Exact match	Learning Spanning tree
IP	Dest IP address Longest prefix match	Routing protocol
TDM	Time slot, exact match Time Slot Exchange (TSE)	E2E signaling protocol Routing protocol
ATM	Label, exact match Label swapping	E2E signaling protocol Routing protocol
MPLS	Label, Dest IP Address	Flexible signaling Routing Protocol

Outline




- Circuit switching refresher
- Virtual Circuits - general
 - Why virtual circuits?
 - How virtual circuits? -- tag switching!
- Two modern implementations
 - ATM - teleco-style virtual circuits
 - MPLS - IP-style virtual circuits
- Virtual LANs
 - How do they differ?

VLAN Introduction



- ◆ VLANs logically segment switched LANs (layer 2!) based on organization or function, independent of their physical location in the network
 - ◆ Devices on a VLAN share their own (private) LAN
 - ◆ Form their own IP subnet
- ◆ Offers many benefits:
 - ◆ Performance: limits broadcast messages to the VLAN – improves scalability
 - ◆ Security: isolates VLAN – VLANs connected by routers with smarter filtering capabilities
 - ◆ Management: manage network topology without changing the physical topology

VLAN Example



- A switch creates a broadcast domain
- VLANs help manage broadcast domains
- VLANs can be defined on port groups, users, or protocols
- LAN switches and network management software provide a mechanism to create VLANs

VLAN Types




- ◆ VLANs are implemented by switches
- ◆ VLAN memberships can be controlled by a switch in different ways, based on:
 - Port: incoming ports are tagged with VLAN ID
 - MAC address: switch has (MAC, VLAN ID) table
 - Protocol: switch as (protocol, VLAN ID) table
- ◆ The frame headers are encapsulated or modified to insert a VLAN ID
 - ◆ Is inserted by first switch before forwarding packet
 - ◆ Removed by last switch before forwarding to the destination device

Example: 802.1Q Standard for VLANs over Ethernet



- A 32 bit VLAN header is inserted after the MAC addresses



- Header consists of
 - Tag Protocol Identifier (16b): single value that marks frame as a VLAN frame
 - Control bits (4b): mostly priority
 - VLAN Identifier (12b): identifies VLAN

43

Take Home Points



- Costs/benefits/goals of virtual circuits
- Cell switching (ATM)
 - Fixed-size pkts: Fast hardware
 - Packet size picked for low voice jitter. Understand trade-offs.
 - Beware packet shredder effect (drop entire pkt)
- Tag/label swapping - basis for most VCs.
 - Makes label assignment link-local. Understand mechanism.
- MPLS - IP meets virtual circuits (links)
 - Used for VPNs, traffic engineering, reduced core routing table sizes
 - Management of ISPs at layer 3
- Virtual LANs – manage LANs in software
 - Simplifies management of edge networks at layer 2
 - Set up by manager based on organizational structure – no tag swapping